

## Scope Stand Cart Mount Instructions

The cart mount is designed to work with Ray-Vin scope stands and Ray-Vin wheel kits. Installation is simple.

1. Loosen the side set screw in the stand base and remove the base plug. Replace it with the cart mount base plug. Orient the plug hole to be parallel with the set screw hole.



2. Install one rod on the upper forward stool leg. Rod should be up with u-bolt pointing down.



3. Install the other rod on the cart handle.



4. Use the hose clamp to secure the stand clip to the upper rod. Face it either inwards or outwards. Tuck the end of the clamp strap into the slot.

With the stand legs folded up, slide the base plug hole onto the lower rod. You can see the set screw hold from the top and this will aid in alignment.



Snap the stand rod into the stand clip. The scope and head should be positioned between the top and bottom mounts.

